



www.allenlighting.com.au  
ABN 99 099 066 083

**Installation instructions for wire suspension:**

Attach A to the mounting surface and screw B to A with the eyelet as shown.

Attach D to the fitting with the supplied 10mm nut (E) and feed the wire through as shown.

To adjust simply push the wire through D until the desired length is attained.  
If re-adjustment is needed push down on spigot C to allow the wire to feed back through.  
Once the desired length is set, cut the wire to length leaving enough to screw the lock collar onto the wire as shown in fig. 2.

Caution: Do **NOT** dismantle D as spring loaded parts may be lost.  
Do not allow excess wire in the fitting that may come in contact with live terminals.

